ELEMENTS OF ARCHITECTURAL STRUCTURES:

FORM, BEHAVIOR, AND DESIGN

DR. ANNE NICHOLS **SPRING 2013**

lecture



beam sections geometric properties

Sections Lecture 8

ARCH 614

\$2009abr

Center of Gravity

• "average" x & y from moment

$$z$$
 $\Delta W_4 \Delta W_1$
 $\Delta W_3 \Delta W_2$
 X

$$\sum M_{y} = \sum_{i=1}^{n} x_{i} \Delta W_{i} = \overline{x} \mathbf{W} \implies \overline{x} = \frac{\sum (x \Delta W)}{\mathbf{W}}$$


$$\sum M_{x} = \sum_{i=1}^{n} y_{i} \Delta W_{i} = \overline{y} \mathbf{W} \implies \overline{y} = \frac{\sum (y \Delta W)}{\mathbf{W}}$$

$$\sum M_{x} = \sum_{i=1}^{n} y_{i} \Delta W_{i} = \bar{y} W \implies \bar{y} = \frac{\sum (y \Delta W)}{W}$$

S2004abr

Center of Gravity

- location of equivalent weight
- determined with calculus



• sum element weights

Centroids 6


Elements of Architectural Structures

S2004abn

Centroid

- "average" x & y of an area
- for a volume of constant thickness
 - $-\Delta W = \gamma t \Delta A$ where γ is weight/volume
 - center of gravity = centroid of area

$$\bar{x} = \frac{\sum (x \Delta A)}{A}$$



Centroids 8

Elements of Architectural Structures

S2004abn

Centroid

• for a line, sum up length

$$\bar{x} = \frac{\sum (x\Delta L)}{L}$$
$$\bar{y} = \frac{\sum (y\Delta L)}{L}$$





Centroids 9

Elements of Architectural Structures

S2004abn


S2004abn

1st Moment Area

- math concept
- the moment of an area about an axis

$$Q_x = \overline{y}A$$






Centroids 10

Elements of Architectural Structures ARCH 614


S2004abn

Symmetric Areas

 symmetric about an axis




- symmetric about a center point
- mirrored symmetry



Composite Areas

- made up of basic shapes
- areas can be <u>negative</u>
- (centroids can be negative for any area)



Centroids 12

Elements of Architectural Structures ARCH 614

S2004abr

Basic Procedure

- 1. Draw reference origin (if not given)
- 2. Divide into basic shapes (+/-)
- 3. Label shapes
- 4. Draw table

Component	Area	\bar{x}	$\bar{x}A$	\bar{y}	$\overline{y}A$
Σ					

- 5. Fill in table
- 6. Sum necessary columns
- 7. Calculate \hat{x} and \hat{y}


Centroids 13

Elements of Architectural Structures ARCH 614 S2004abr

GRITICAL

Moments of Inertia

- 2nd moment area
 - math concept
 - area x (distance)²
- · need for behavior of
 - beams
 - columns



Moment of Inertia 4 Lecture 11 Elements of Architectural Structures S2004abr.
ARCH 614

Area Centroids

• Figure A.1 – pg 598

Centroids of Common Shapes of Areas and Lines

Shape		x	y
Triangular area	1	$\frac{b}{3}$ right triangle only	$\frac{h}{3}$
Quarter-circular area		$\frac{4r}{3\pi}$	$\frac{4r}{3\pi}$
Semicircular area	$\frac{0}{ \bar{x} }$	0	$\frac{4r}{3\pi}$
Semiparabolic area	← a →	3 <i>a</i> 8	$\frac{3h}{5}$
Parabolic area	$0 \bar{x} 0 -a $	0	$\frac{3h}{5}$

Centroids 14


Elements of Architectural Structures ARCH 614 S2004abr

Moment of Inertia

- about any reference <u>axis</u>
- can be negative

$$I_{y} = \sum x_{i}^{2} \Delta A = \int x^{2} dA$$

$$I_{x} = \sum y_{i}^{2} \Delta A = \int y^{2} dA$$
$$(or \ I_{x-x} = \sum z^{2} a)$$




· resistance to bending and buckling

Moment of Inertia 5

Elements of Architectural Structures ARCH 614 S2004abn

Moment of Inertia

- same area moved away a distance
 larger I
 - larger I




Moment of Inertia 6 Lecture 11 Elements of Architectural Structures ARCH 614 S2004abn

Radius of Gyration

· measure of inertia with respect to area

$$r_{x} = \sqrt{\frac{I_{x}}{A}}$$



When a figure skater changes position, he or she is redistributing his or her mass. Thus, every position has it's own unique rotational inertia.



The rotational inertia of the figure skater increases when her arms are raised because more of her mass is redistributed further from her axis of rotation.


Moment of Inertia 8 Elements of Architectural Structures
Lecture 11 ARCH 614

S2004abn

Polar Moment of Inertia

- for roundish shapes
- uses polar coordinates (r and θ)
- resistance to twisting

$$J_o = \int r^2 dA$$




Moment of Inertia 7 Lecture 11 Elements of Architectural Structures ARCH 614 S2004abn

Parallel Axis Theorem

• can find composite *I* once composite centroid is known (basic shapes)

$$I = I_o + Az^2$$
$$= \bar{I}_x + Ad_y^2$$



$$I = \sum \bar{I} + \sum Ad^2$$

$$\bar{I} = I - Ad^2$$

Moment of Inertia 9 Lecture 11 Elements of Architectural Structures ARCH 614 S2005abn

Basic Procedure

- 1. Draw reference origin (if not given)
- 2. Divide into basic shapes (+/-)
- 3. Label shapes
- 4. Draw table with A, \bar{x} $\bar{x}A$ \bar{y} $\bar{y}A$ \bar{I} 's, d's, and Ad²'s
- 5. Fill in table and get \hat{x} and \hat{y} for composite
- 6. Sum necessary columns
- 7. Sum I's and Ad²'s

$$(d_x = \hat{x} - \overline{x}) (d_y = \hat{y} - \overline{y})$$

Moment of Inertia 8


Elements of Architectural Structures ARCH 614 S2006abr

Area Moments of Inertia

• Figure A.11 – pg. 611: (bars refer to centroid)

$$-x', y'$$

-C



Moment of Inertia 11 Lecture 11 S2005abn