


lecture
twenty five

concrete construction: columns & frames


Concrete Columns 1
Lecture 25Elements of Architectural Structures
ARCH 614

S2009abn

<http://www.bam.de>

Concrete in Compression

- crushing
- vertical cracking
 - tension
- diagonal cracking
 - shear
- f'_c

Concrete Columns 2
Lecture 25Elements of Architectural Structures
ARCH 614

S2007abn

Slenderness

- effective length in monolithic with respect to stiffness of joint: Ψ & k
- not slender when

$$\frac{kL_u}{r} < 22$$




Figure 5-7 Column Tie Details

Concrete Columns 3
Lecture 25Elements of Architectural Structures
ARCH 614


S2007abn

Concrete Columns 4
Lecture 25Elements of Architectural Structures
ARCH 614


S2007abn

Effective Length (revisited)


- relative rotation



(a)
Nonsway Frames



(b)
Sway Frames



$$\Psi = \frac{\sum EI/l_c}{\sum EI/l_b}$$

Concrete Columns 5
Lecture 25

Elements of Architectural Structures
ARCH 614

S2007abn

Column Behavior




Figure 13.3.2 Spirally reinforced column behavior. (Courtesy of Portland Cement Association.)




Figure 13.3.3 Tied column behavior. (Courtesy of Portland Cement Association.)

Concrete Columns 6
Lecture 25

Elements of Architectural Structures
ARCH 614

S2007abn

Column Design

- $\phi_c = 0.65$ for ties, $\phi_c = 0.75$ for spirals
- P_o – no bending

$$P_o = 0.85 f'_c (A_g - A_{st}) + f_y A_{st}$$

$$P_u \leq \phi_c P_n$$


– ties: $P_n = 0.8P_o$

– spiral: $P_n = 0.85P_o$

- nominal axial capacity:

– presumes steel yields

– concrete at ultimate stress



Concrete Columns 7
Lecture 25

Elements of Architectural Structures
ARCH 614

S2007abn

Columns with Bending

- eccentric loads can cause moments
- moments can change shape and induce more deflection
($P-\Delta$)





Figure 10.6 Considerations for development of bending in steel columns: (a) bending induced by eccentric load, (b) bending transferred to column in a rigid frame, and (c) combined loading condition, separately producing axial compression and bending.

Concrete Columns 8
Lecture 25

Elements of Architectural Structures
ARCH 614

S2007abn

Columns with Bending

- for ultimate strength behavior, ultimate strains can't be exceeded
 - concrete 0.003
 - steel $\frac{f_y}{E_s}$
- P reduces with M




Figure 13.6.1 Typical strength interaction diagram for axial compression and bending moment about one axis. Transition zone is where $\epsilon_{t,y} \leq \epsilon_t \leq 0.005$.

Concrete Columns 9
Lecture 25

Elements of Architectural Structures
ARCH 614

S2007abn

Columns with Bending

- need to consider combined stresses
- linear strain
- steel stress at or below f_y
- plot interaction diagram




Figure 5-3 Transition Stages on Interaction Diagram

Concrete Columns 10
Lecture 25

Elements of Architectural Structures
ARCH 614

S2007abn

Design Methods

- calculation intensive
 - handbook charts
 - computer programs





Figure 5-17 12 x 12 in. Column Design Chart

Concrete Columns 11
Lecture 25

Elements of Architectural Structures
ARCH 614

S2007abn

Design Considerations

- bending at both ends
 - $P - \Delta$ maximum
- biaxial bending
- walls
 - unit wide columns
 - “deep” beam shear
- detailing
 - shorter development lengths
 - dowels to footings






Figure 12-1 Biaxial Interaction Surface



(c) Footing without Pedestal

Concrete Columns 12
Lecture 25

Elements of Architectural Structures
ARCH 614

S2007abn