
Architectural Structures: Form, Behavior, and Design Arch 331 Dr. Anne Nichols Summer 2013 Iecture

# structural behavior, systems, and design

one

### Syllabus & Student Understandings



### **Course Description**

statics

- physics of forces and reactions on bodies and systems
- equilibrium (bodies at rest)
- structures

 something made up of interdependent parts in a definite pattern of organization

• design

 assessing and meeting structural requirements of parts and the whole


Introduction 3 Lecture 1

### **Course Description**

- mechanics of materials
  - external loads and effect on deformable bodies
  - use it to answer question if structure meets requirements of
    - stability and equilibrium
    - strength and stiffness
  - other principle building requirements
    - economy, functionality and aesthetics

#### Structure Requirements

stability & equilibrium
 STATICS



### Structure Requirements (cont)

 strength & stiffness

 concerned with stability of components




Figure 1.15 Stability and the strength of a structure—the collapse of a portion of the UW Husky stadium during construction (1987) due to a lack of adequate bracing to ensure stability. Photo by author.

### Structural System Selection

- kind & size of loads
- building function
- soil & topology of site
- systems integration
- fire rating
- construction (\$\$, schedule)
- architectural form

# Knowledge Required

- external forces
- internal forces
- material properties
- member cross sections



- ability of a material to resist breaking
- structural elements that resist excessive – deflection
  - deformation

## **Problem Solving**

#### 1. STATICS:

equilibrium of external forces, internal forces, <u>stresses</u>

#### 2. GEOMETRY:



cross section properties, deformations and conditions of geometric fit, <u>strains</u>

3. MATERIAL PROPERTIES:

<u>stress-strain relationship</u> for each material obtained from testing

#### **Relation to Architecture**

"The geometry and arrangement of the load-bearing members, the use of materials, and the crafting of joints all represent opportunities for buildings to express themselves. The best buildings are not designed by architects who after resolving the formal and spatial issues, simply ask the structural engineer to make sure it doesn't fall down." - Onouye & Kane Statics and Strength of Materials for


Architecture and Building Construction

### Architectural Space and Form

- evolution traced to developments in structural engineering and material technology
  - stone & masonry
  - timber
  - concrete
  - cast iron, steel
  - tensile fabrics, pneumatic structures.....

### Architectural Space and Form

- structure is a device for channeling loads that result from the use and/or presence of the building to the ground
  - span a roof
  - hold up a floor
  - cross a river
  - suspend a canopy



www.pbs.org/wgbh/buildingbig/

- axial tension
   bending
- axial compression




Figure 1.2 (a) Axial tension, (b) axial compression, and (c) bending.

#### member breadth & depth









Figure 1.4 (a) A very shallow beam and (b) a deep beam.




Introduction 14 Lecture 1 Architectural Structures ARCH 331 Su2013abn


stabilization








#### • shear & bracing





(b)

Figure 1.29 (a, b) Structural frame stabilized by adding shear panels.





Figure 1.30 Bracing with (a) triangulation and (b) a rigid frame.

(a)

lateral resistance








Figure 1.32 (a) A thin-shelled barrel vault and (b) a thin-shelled cross vault.







Architectural Structures ARCH 331 Su2013abn

• twisting






Figure 1.35 Torsion in a tube, a slab, and an I-section.




## Structural Design

- planning
- preliminary structural configuration
- determination of loads
- preliminary member selection
- analysis
- evaluation
- design revision
- final design



- STATIC and DYNAMIC
- dead load
  - static, fixed, includes building weight, fixed equipment
- live load
  - transient and moving loads (including occupants), snowfall



Architectural Structures ARCH 331

Su2013abn

#### wind loads

dynamic, wind pressures treated as lateral static loads on walls, up or down loads on

roofs







Figure 1.13 Wind loads on a structure.





earthquake loads
 seismic, movement of ground ↓ ↔






impact loads
 rapid, energy loads





- gravity acts on mass (F=m\*g)
- force of mass
  - acts at a point
    - ie. joist on beam
  - acts along a "line"
    - *ie. floor on a beam*
  - acts over an area
    - *ie. people, books, snow on roof or floor*



### Structural Math

- quantify environmental loads
   how big is it?
- evaluate geometry and angles
  - where is it?
  - what is the scale?
  - what is the size in a particular direction?
- quantify what happens in the structure


   how big are the internal forces?
   how big should the beam be?

#### Structural Math

- physics takes observable phenomena and relates the measurement with rules: <u>mathematical relationships</u>
- need
  - reference frame
  - measure of length, mass, time, direction, velocity, acceleration, work, heat, electricity, light
  - calculations & geometry

## Structural Organization

- classifications
   geometry
  - line-forming
  - surface-forming
  - stiffness
    - rigid
    - flexible




one-way or two-way

spatial organization and load transfer


- materials

### Structural Components

- bearing walls
- columns
- beams
- flat plates
- trusses
- arches
- shells
- cables




# **Bearing Walls**




Introduction 29 Lecture 1 Architectural Structures ARCH 331 Su2013abn

### **Bearing Walls**

#### • behavior as "deep beams"




### Columns & Walls




Introduction 31 Lecture 1 Architectural Structures ARCH 331 Su2013abn


#### **Beams & Plates**




### **Beams & Plates**




### **Trusses and Shells**





### Arches and Cables






(c) Uniform loads (horizontally)—parabola.






# **Building Framing**


#### Components or Assemblages



(a) Common types of horizontal spanning systems (one, two, and three level systems) used in relation to different types of load-bearing wall and columnar vertical support systems.

## **Building Framing**






Architectural Structures ARCH 331 \*\*\*\*

### System Selection

#### evaluation of alternatives




DESIGN CRITERIA	Light-frame timber	Heavy-frame timber	Masonry bearing wall	Steel frame (hinge connections)	Steel frame (rigid connections)	Steel open-web joists	Steel space frame	Steel decking	Site-cast concrete: one-way slab	Site-cast concrete: two-way plate	Site-cast concrete: two-way slab	Site-cast concrete: one-way joists	Site-cast concrete: waffle slab	Precast concrete: solid slab	Precast concrete: hollow-core slab	Precast concrete: single tee	Precast concrete: double tee	RATIONALE
Exposed, fire-resiant construction	+			-														Inherently fire-resistive construction
Irregular building form				-														Simple, site-fabricated systems
Irregular column placement	611053		and the	-								-						Systems without beams in roof or floors
Minimize floor thickness											ere on		000000					Precast-concrete systems without ribs
Allow for future renovations																		Short-span, one-way, easily modified
Permit construction in poor weather										8		10121220						Quickly erected; avoid site-cast concrete
Minimize off-site fabrication time							2.8850									1000000		Easily formed or built on site
Minimize on-site erection time	10499500		annes.						180,000									Highly prefabricated; modular components
Minimize low-rise construction time										İ						- Second		Lightweight, easily formed or prefabricated
Minimize medium-rise construction time		1																Precast, site-cast concrete; steel frames
Minimize high-rise construction time										and a second sec			and a second sec					Strong; prefabricated; lightweight
Minimize shear walls or diagonal bracing		1							1.5									Capable of forming rigid joints
Minimize dead load on foundations			and a second															Lightweight, short-span systems
Minimize damage due to foundation settlement																		Systems without rigid joints
Minimize the number of separate trades on job							1											Multipurpose components
Provide concealed space for mech. services														-				Systems that inherently provide voids
Minimize the number of supports			6															Two-way, long-span systems
Long spans																		Long-span systems


### Structural Design Criteria

- components stay together
- structure acts as whole to be stable
  - resist sliding
  - resist overturning
  - resist twisting and distortion
- internal stability
  - interconnectedness
- strength & stiffness





Overturning: wind or earthquake




Lateral racking

Introduction 40 Lecture 1 Architectural Structures ARCH 331 Su2013abn


#### Structural Design Sequences


- first-order design
  - structural type and organization
  - design intent
  - contextual or programmatic
- second-order
  - structural strategies
  - material choice
  - structural systems
- third-order
  - member shaping & sizing




### Systems by Materials

- Wood
- Steel
- Concrete
- Masonry
- Composite









### Wood

- columns
- beams
- trusses



- all-wood framing systems
  - studs, beams, floor diaphragms, shearwalls
  - glulam arches & frames
  - post & beams
  - trusses
- composite construction
  - masonry shear walls
  - concrete
  - steel







Introduction 44 Lecture 1


- studs, beams
- floor diaphragms & shear walls





- glulam arches & frames
  - manufactured or custom shapes
  - glue laminated
  - bigger members





post & beam



#### • trusses




composite construction



Introduction 48 Lecture 1 Architectural Structures ARCH 331 Su2013abn

#### **Steel**


- cast iron wrought iron steel
- cables
- columns
- beams
- trusses
- frames




Introduction 49 Lecture 1 Su2013abn

#### **Steel Construction**


- standard rolled shapes
- open web joists
- plate girders
- decking






#### **Steel Construction**

- welding
- bolts







### **Steel Construction**

- fire proofing

   cementicious spray
   encasement in gypsum
  - intumescent expands
     with heat
  - sprinkler system







Introduction 52 Lecture 1 Architectural Structures ARCH 331 Su2013abn

## Concrete

- columns
- beams
- slabs
- domes
- footings







Architectural Structures http://nisee.berkeley.edu/godden ARCH 331 Su2013abn


### **Concrete Construction**

- cast-in-place
- tilt-up
- prestressing
- post-tensioning









Tied

Spirally reinforced column





Introduction 54 Lecture 1


Architectural Structures **ARCH 331** 

http://nisee.berkeley.edu/godden




#### Concrete Floor Systems

types & spanning direction



### Concrete Floor Systems



Introduction 56 Lecture 1


# Masonry (& Stone)


- columns
- walls
- lintels
- beams
- arches
- footings




### Grids and Patterns

- often adopted early in design
  - give order
  - cellular, ex.
- vertical and horizontal
- square and rectangular
  - single-cell
  - aggregated bays






#### **Grids and Patterns**




### **Systems**


- total of components
- behavior of whole
- classifications
  - one-way
  - two-way
  - tubes
  - braced
  - unbraced



 (c) Two-way flat-plate system (without beams) for a hexagonal or circular configuration.




 (a) One-way radial beam-and-column system for a hexagonal or circular configuration.



(b) One-way circumferential beamand-column system plan for hexagonal or circular configuration.


### **One-Way Systems**

### horizontal vs. vertical




## Two-Way Systems

- spanning system less obvious
- horizontal
  - plates
  - slabs
  - space frames
- vertical
  - columns
  - walls




### Two-Way Systems



Introduction 63 Lecture 1

# **Roof Shapes**


- coincide
- within





Introduction 64 Lecture 1 Architectural Structures ARCH 331 Su2013abn


### **Tubes & Cores**

#### • stiffness










(d) Tube structure. The exterior columns are closely spaced. Horizontal spandrel beams are rigidly connected to columns. to form an exterior tube, which carries all lateral forces and some gravity forces. Interior columns carry only vertical forces.

Introduction 65 Lecture 1

# Span Lengths

- crucial in selection of system
- maximum spans on charts aren't absolute limits, but <u>usual maximums</u>



- increase L, increase depth<sup>2</sup> required (ex. cantilever)
- deflections depend on L

### Approximate Depths


Introd Lectu

			Span												
			0 10 20	30 40 50	60 70	80 90	100 110	120 130	0 140 15	50 160	170 180				
Slabs (poured in place)		Simply supported L/25 One end L/30 Both ends L/35 continuous									Key:	Minimum span -	*	Possible span ->	Maximun
		Cantilever L/12									-	span		range	span
Beams (poured in place)		Simply L/20 Supported L/20 One end L/23 Both ends L/26 continuous L/26										ypical span or member -			
		Cantilever L/10	₩,											' Typical member length	
Pan joist system (poured in place)		L/20–L/25												member length	
Folded plate (poured in place)		<i>L</i> /8– <i>L</i> /15													
Barrel shell (poured in place)	Y Y	<i>L</i> /8– <i>L</i> /15													
Planks (precast)	200003	<i>L</i> /25– <i>L</i> /40													
Channels (precast)	$\nabla = \nabla$	L/20–L/28													
Tees (precast)		L/20–L/28				-									
Flat plate (poured in place)		<i>L</i> /30– <i>L</i> /40													
Flat slab (poured in place)		<i>L</i> /30– <i>L</i> /40													
Two-way beam and slab (poured in place		<i>L</i> /30– <i>L</i> /40													
Waffle slab (poured in place)		L/23–L/35													
Dome (poured in place) ion 67		L/4—L/8												Su2013abn	
1		(Meters)	L	10 15	20		-	1	10	45					


## Loading Type and Structure Type

- light uniform loads
  - surface forming elements
  - those that pick up first load dictate spacing of other elements
- heavy concentrated loads
  - member design unique
- distributed vs. concentrated structural strategies
  - large beam vs. many smaller ones


lateral stability – all directions




configuration




Stabilizing elements may be placed within the interior or at the perimeter of a building.




Stabilizing elements should be arranged in a balanced fashion.




Rigid frame structures require no additional bracing or shear walls, as shown in this elevation and plan.





The locations of braced frames or shear walls must be considered in relation to the elevation and plan of the building.


#### vertical load resistance



walls

#### columns

#### lateral load resistance




Shear walls may be arranged in a box form to resist lateral forces from all directions.

When combined with other stabilizing mechanisms, shear walls may be arranged so as to resist forces in only one direction of a building.

#### **Design Issues**

#### lateral load resistance




Shear walls are commonly used with column and slab systems. In this elevation and plan, the shear walls are shown incorporated into a pair of vertical cores.

Rigid frame structures require no additional bracing or shear walls, as shown in this elevation and plan.

The locations of braced frames or shear walls must be considered in relation to the elevation and plan of the building.


### **Design Issues**

- multi-story
  - cores, tubes, braced frames




## **Design Issues**

- multi-story
  - avoid discontinuities
    - vertically
    - horizontally





Transfer beams or trusses may be used to interrupt vertical loadbearing elements where necessary.



UNBALANCED PLAN

BALANCED PLAN





Discrete building masses should be structurally independent. Inherently unstable building masses should be avoided.


$\overline{\Box}$	Liberie	
	NEM 78	


Discontinuities in the stiffness of structures at different levels should be avoided, or additional stabilizing elements may be required.

Architectural Structures ARCH 331

## Foundation Influence


- type may dictate fit
  - piles vs. mats vs. spread
  - capacity of soil to sustain loads
    - high capacity smaller area of bearing needing and can spread out
    - low capacity multiple contacts and big distribution areas






## Grid Dependency on Floor Height

- wide grid = deep beams
  - increased building height
  - heavier
  - foundation design
- codes and zoning may limit
- utilize depth for mechanical



# Large Spaces

- ex. auditoriums, gyms, ballrooms
- choices
  - separate two systems completely and connect along edges
  - embed in finer grid
  - staggered truss




#### Meeting of Grids

- common to use more than one grid
- intersection important structurally
- can use different structural materials
   need to understand their properties
  - mechanical
  - thermal

## Meeting of Grids


horizontal choices



Architectural Structures ARCH 331

## Meeting of Grids

vertical choices




(a) Alignment of grids.


(b) Bypassing of grids.

## **Other Conditions**

- circulation
- building service systems
  - one-way systems have space for parallel runs




- trusses allow for transverse penetration
- pass beneath or interstitial floors
  - for complex or extensive services or flexibility




## **Other Conditions**

- poking holes for member services

   horizontal
  - need to consider area removed, where removed, and importance to shear or bending
  - vertical
    - requires framing at edges
    - can cluster openings to eliminate a bay
  - double systems





#### Fire Safety & Structures

- fire safety requirements can impact structural selection
- construction types
  - light
    - residential
    - wood-frame or unprotected metal
  - medium
    - masonry
  - heavy
    - protected steel or reinforced concrete

#### Fire Safety & Structures

- degree of occupancy hazards
- building heights
- maximum floor areas between fire wall divisions
  - can impact load bearing wall location

#### Fire Safety & Structures

- resistance ratings by failure type
  - transmission failure
    - fire or gasses move
  - structural failure
    - high temperatures reduce strength
  - failure when subjected to water spray
    - necessary strength
- ratings <u>do not pertain</u> to usefulness of structure after a fire



