

lecture
thirteen

wood construction:
column design

Wood Columns 1
Lecture 13


Architectural Structures
ARCH 331



F2009abn

Compression Members (revisited)

- designed for strength & stresses
- designed for serviceability & deflection
- need to design for stability
 - ability to support a specified load without sudden or unacceptable deformations





Wood Columns 2
Lecture 16

Foundations Structures
ARCH 331

F2008abn

Effect of Length (revisited)

- long & slender
- short & stubby




Wood Columns 3
Lecture 16

Foundations Structures
ARCH 331

F2008abn

Critical Stresses (revisited)

- when a column gets stubby, crushing will limit the load
- real world has loads with eccentricity




Wood Columns 4
Lecture 16

Elements of Architectural Structures
ARCH 614

S2009abn

Bracing (revisited)

- bracing affects shape of buckle in one direction
- both should be checked!



Wood Columns 5
Lecture 16

Foundations Structures
ARCH 331



F2008abn

Wood Columns

- slenderness ratio = L/d_{min}
 - d_1 = smallest dimension
 - $L_e/d \leq 50$ (max)

$$f_c = \frac{P}{A} \leq F'_c$$

- where F'_c is the allowable compressive strength parallel to the grain
- bracing common
- posts, round, built-up



Wood Columns 6
Lecture 16

Elements of Architectural Structures
ARCH 614

S2009abn

Allowable Wood Stress

$$F'_c = F_c (C_D)(C_M)(C_t)(C_F)(C_p)$$

- where:

F_c = compressive strength parallel to grain


C_D = load duration factor

C_M = wet service factor (1.0 dry)

C_t = temperature factor

C_F = size factor


C_p = column stability factor



(Table 10.3)

Strength Factors

- wood properties and load duration, C_D
 - short duration
 - higher loads
 - normal duration
 - > 10 years



<http://www.swst.org/teach/set2/struct1.html>

- stability, C_p

– combination curve - tables

$$F'_c = F_c^* C_p = (F_c C_D) C_p$$

Wood Columns 7
Lecture 16

Foundations Structures
ARCH 331

F2008abn

Wood Columns 8
Lecture 16

Foundations Structures
ARCH 331

F2008abn

C_p Charts – Appendix A

Table 14 Column Stability Factor C_p

"C _p "			$F'_c = C_p \cdot F_c^*$			$F_{cE} = \frac{.30 E}{(l/d)^2}$ for sawed posts			$F_{cE} = \frac{.418 E}{(l/d)^2}$ for glu-lam posts		
$\frac{F_{cE}}{F'_c}$	Sawed	Glu-Lam	$\frac{F_{cE}}{F'_c}$	Sawed	Glu-Lam	$\frac{F_{cE}}{F'_c}$	Sawed	Glu-Lam	$\frac{F_{cE}}{F'_c}$	Sawed	Glu-Lam
	C _p	C _p		C _p	C _p		C _p	C _p		C _p	C _p
0.00	0.000	0.000	0.40	0.360	0.377	0.80	0.610	0.667	1.20	0.750	0.822
0.01	0.010	0.010	0.41	0.367	0.386	0.81	0.614	0.672	1.22	0.755	0.826
0.02	0.020	0.020	0.42	0.375	0.394	0.82	0.619	0.678	1.24	0.760	0.831
0.03	0.030	0.030	0.43	0.383	0.403	0.83	0.623	0.683	1.26	0.764	0.836
0.04	0.040	0.040	0.44	0.390	0.411	0.84	0.628	0.688	1.28	0.769	0.840
0.05	0.049	0.050	0.45	0.398	0.420	0.85	0.632	0.693	1.30	0.773	0.844
0.06	0.059	0.060	0.46	0.405	0.428	0.86	0.637	0.698	1.32	0.777	0.848
0.07	0.069	0.069	0.47	0.412	0.436	0.87	0.641	0.703	1.34	0.781	0.852
0.08	0.079	0.079	0.48	0.419	0.444	0.88	0.645	0.708	1.36	0.785	0.855
0.09	0.088	0.089	0.49	0.427	0.453	0.89	0.649	0.713	1.38	0.789	0.859
0.10	0.098	0.099	0.50	0.434	0.461	0.90	0.653	0.718	1.40	0.793	0.862
0.11	0.107	0.109	0.51	0.441	0.469	0.91	0.658	0.722	1.42	0.796	0.865
0.12	0.117	0.118	0.52	0.448	0.477	0.92	0.661	0.727	1.44	0.800	0.868
0.13	0.126	0.128	0.53	0.454	0.484	0.93	0.665	0.731	1.46	0.803	0.871
0.14	0.136	0.138	0.54	0.461	0.492	0.94	0.669	0.735	1.48	0.807	0.874
0.15	0.145	0.147	0.55	0.468	0.500	0.95	0.673	0.740	1.50	0.810	0.877
0.16	0.154	0.157	0.56	0.474	0.508	0.96	0.677	0.744	1.52	0.813	0.879
0.17	0.164	0.167	0.57	0.481	0.515	0.97	0.680	0.748	1.54	0.816	0.882
0.18	0.173	0.176	0.58	0.487	0.523	0.98	0.684	0.752	1.56	0.819	0.884
0.19	0.182	0.186	0.59	0.494	0.530	0.99	0.688	0.756	1.58	0.822	0.887

Wood Columns 9
Lecture 16

Foundations Structures
ARCH 331

F2008abn

Procedure for Analysis

- calculate L_e/d_{min}
 - KL/d each axis, choose largest
- obtain F'_c
 - compute $F_{cE} = \frac{K_{cE} E}{(L_e/d)^2}$
 - $K_{cE}=0.3$ sawn
 - $K_{cE}=0.418$ glu-lam
- compute $F_c^* \approx F_c C_D$
- calculate F_{cE}/F_c^* and get C_p (Table 14)
- calculate $F'_c = F_c^* C_p$

Wood Columns 11
Lecture 16

Foundations Structures
ARCH 331

F2008abn

Column Charts – Appendix A, 12 & 13

Table 12 Allowable Column Loads—Selected Species/Sizes. (Continued)

Eff.	Col.	l/d	(l/d) ²	F _{cE}	F _{cE} /F' _c	C _p	F' _c (psi)	P _a (k)	8×8	A = 56.25	8×10	A = 71.25	8×12	A = 86.25	
Len(ft)							Norm	Snow	Norm	Snow	Norm	Snow	Norm	Snow	
12	19.2	368.64	1302.08	1.30	1.13	.7731	.7315	.773	841	43.5	47.3	55.1	59.9	66.7	72.6
13	20.8	432.64	1109.47	1.11	0.96	.7258	.6767	.726	778	40.8	43.8	51.7	55.4	62.6	67.1
14	22.4	501.76	956.63	0.96	0.83	.6767	.6235	.677	717	38.1	40.3	48.2	51.1	58.4	61.8
15	24.00	576.00	833.33	0.83	0.72	.6235	.5694	.624	655	35.1	36.8	44.4	46.7	53.8	56.5
16	25.60	655.36	732.42	0.73	0.64	.5747	.5244	.575	603	32.3	33.9	40.9	43.0	49.6	52.0
17	27.20	739.84	648.79	0.65	0.56	.5303	.4744	.530	546	29.8	30.7	37.8	38.9	45.7	47.1
18	28.80	829.44	578.70	0.58	0.50	.4873	.4336	.487	499	27.4	28.0	34.7	35.5	42.0	43.0
19	30.40	924.16	519.39	0.52	0.45	.4475	.3975	.448	457	25.2	25.7	31.9	32.6	38.6	39.4
20	32.00	1024.00	468.75	0.47	0.41	.4122	.3673	.412	422	23.2	23.8	29.4	30.1	35.6	36.4
21	33.60	1128.96	425.17	0.43	0.37	.3826	.3360	.383	386	21.5	21.7	27.3	27.5	33.0	33.3
22	35.20	1239.04	387.40	0.39	0.34	.3518	.3118	.352	359	19.8	20.2	25.1	25.5	30.3	30.9
23	36.80	1354.24	354.44	0.35	0.31	.3199	.2869	.320	330	18.0	18.6	22.8	23.5	27.6	28.5
24	38.40	1474.56	325.52	0.33	0.28	.3035	.2615	.304	301	17.1	16.9	21.6	21.4	26.2	25.9
25	40.00	1600.00	300.00	0.30	0.26	.2785	.2442	.279	281	15.7	15.8	19.8	20.0	24.0	24.2
26	41.60	1730.56	277.37	0.28	0.24	.2615	.2267	.262	261	14.7	14.7	18.6	18.6	22.6	22.5
27	43.20	1866.24	257.20	0.26	0.22	.2442	.2090	.244	240	13.7	13.5	17.4	17.1	21.1	20.7
28	44.80	2007.04	239.16	0.24	0.21	.2267	.2000	.227	220	12.8	12.9	16.2	16.4	19.6	19.8
29	46.40	2152.96	222.95	0.22	0.19	.2090	.1819	.209	209	11.8	11.8	14.9	14.9	18.0	18.0
30	48.00	2304.00	208.33	0.21	0.18	.2000	.1728	.200	199	11.3	11.2	14.3	14.2	17.3	17.1
	DF-L No.1	(P&T)		F _c = 1000		E = 1.6									
	DF-L No.1 & Btr/Dm.Lum			F _c = 1500		E = 1.8									

Wood Columns 10
Lecture 16

Foundations Structures
ARCH 331

F2008abn

Procedure for Analysis (cont'd)

- compute $P_{allowable} = F'_c \cdot A$
 - or find $f_{actual} = P/A$
- is $P \leq P_{allowable}$? (or $f_{actual} \leq F'_c$?)
 - yes: OK
 - no: overstressed & no good

Wood Columns 12
Lecture 16

Foundations Structures
ARCH 331

F2008abn

Procedure for Design

1. guess a size (pick a section)
2. calculate L_e/d_{min}
 - KL/d each axis, choose largest
3. obtain F'_c
 - compute $F_{cE} = \frac{K_{cE} E}{(L_e/d)^2}$
 - $K_{cE}=0.3$ sawn
 - $K_{cE}=0.418$ glu-lam
4. compute $F_c^* \approx F_c C_D$
5. calculate F_{cE}/F_c^* and get C_p (Table 14)

Wood Columns 13
Lecture 16

Foundations Structures
ARCH 331

F2008abn

Procedure for Design (cont'd)

6. compute $F'_c = F_c^* C_p$
7. compute $P_{allowable} = F'_c \cdot A$
 - or find $f_{actual} = P/A$
8. is $P \leq P_{allowable}$? (or $f_{actual} \leq F'_c$?)
 - yes: OK
 - no: pick a bigger section and **go back to step 2.**

Wood Columns 14
Lecture 16

Foundations Structures
ARCH 331

F2008abn


Timber Construction by Code

- light-frame
 - light loads
 - 2x's
 - floor joists – 2x6, 2x8, 2x10, 2x12 typical at spacings of 12", 16", 24"
 - normal spans of 20-25 ft or 6-7.5 m
 - plywood spans between joists
 - stud or load-bearing masonry walls
 - limited to around 3 stories – fire safety




Design of Columns with Bending


- satisfy
 - strength
 - stability
- pick
 - section




(a) Framed beam (shear) connection.
 $e = \text{Eccentricity}; M = P \times e$



(b) Moment connection (rigid frame).
 $M = \text{Moment due to beam bending}$



(c) Timber beam-column connection.
 $e = d/2 = \text{eccentricity}; M = P \times e$



(d) Upper chord of a truss—compression plus bending.
 $M = \frac{w l^2}{8}$

Wood Columns 15
Lecture 16

Foundations Structures
ARCH 331

F2008abn

Wood Columns 16
Lecture 16

Foundations Structures
ARCH 331

F2008abn

Design

• Wood

$$\left[\frac{f_c}{F'_c} \right]^2 + \frac{f_{bx}}{F'_b \left[1 - \frac{f_c}{F_{cEx}} \right]} \leq 1.0$$

[] term – magnification factor for P-Δ

F'_{bx} – allowable bending strength


Laminated Timber Arches

- two & three hinged arches
- bent to wide range of curves
- bending and compression
- residual stress from laminating, C_c



Design Steps Knowing Loads

1. assume limiting stress
 - buckling, axial stress, combined stress
2. solve for r , A or S
3. pick trial section
4. analyze stresses
5. section ok?
6. stop when section is ok



Laminated Arch Design

- radius of curvature, R , limited by lam thickness, t
 - $R = 100t$ – southern pine & hardwoods
 - $R = 125t$ – softwood
- $r =$ radius to inside face of laminations
- $C_c = 1 - 2000 \left(\frac{t}{r} \right)^2$
- $F'_b = F_b (C_F C_c)$




Fig. 24.6 Circular arch moment analysis