ARCHITECTURAL STRUCTURES: FORM, BEHAVIOR, AND DESIGN

ARCH 331 DR. ANNE NICHOLS SUMMER 2013

twenty four



masonry construction: beams & columns

Masonry Construction 1 Lecture 24

Architectural Structures ARCH 331


F2009abn

Masonry Design

Masonry Standards Joint Committee

- ACI, ASCE, TMS
- ASD (+empirical)
 - · linear-elastic stresses
- LRFD added in 2002
- referenced by IBC
- unreinforced allows tension in flexure
- reinforced all tension in steel
- walls are also in compression

Office Hours



Masonry Construction 2 Lecture 28

Foundations Structures ARCH 331

F2009ahn

Masonry Beam & Wall Design

 reinforcement increases capacity & ductility





Figure 2.10 Reinforced masonry beams and lintels.

Masonry Construction 3

Foundations Structures

Masonry Design

- f_s is not the yield stress
- *f_m* is the stress in the masonry



Masonry Materials


- mortar
 - water, masonry cement, sand, lime
 - types:
 - higher strength 2500 psi (ave.)
 - medium high strength 1800 psi
 - medium strength 750 psi
 - medium low strength 350 psi
 - low strength 75 psi

National Concrete Masonry Association

F2008abn

Masonry Materials

- units
 - stone, brick, concrete block, clay tile



Masonry Materials

- rebar
- grout
 - fills voids and fixes rebar
- prisms
 - used to test strength, f'_{m}
- fire resistant




Ryan-Briggs Asso



Foundations Structures ARCH 331

Masonry Materials

- · moisture resistance
 - weathering index for brick
 - bond and detailing
 - expansion or shrinking from water
 - provide control joints
 - parapets, corners, long walls



parapet with no control joint

Masonry Construction 8 Lecture 28 Foundations Structures ARCH 331 F2008abn

WEATHERING REGIONS

WEGLIGIBLE WEATHERING

MODERATE WEATHERING


Masonry Walls


tension normal to bed joints

WALLS

Not allowed in MSJC code

tension parallel to bed joints





Masonry Construction 10 Foundations Structures
Lecture 28 ARCH 331

F2008abn

Allowable Masonry Stresses

• tension - unreinforced only

Table 2.2.3.2 — Allowable flexural tensile stresses for clay and concrete masonry, psi (kPa)

Direction of flexural tensile stress and masonry type	Mortar types			
	Portland cement/lime or mortar cement		Masonry cement or air entrained portland cement/lime	
	M or S	N	M or S	N
Normal to bed joints				
Solid units	53 (366)	40 (276)	32 (221)	20 (138)
Hollow units ¹				
Ungrouted	33 (228)	25 (172)	20 (138)	12 (83)
Fully grouted	86 (593)	84 (579)	81 (559)	77 (531)
Parallel to bed joints in running bond				
Solid units	106 (731)	80 (552)	64 (441)	40 (276)
Hollow units				
Ungrouted and partially grouted	66 (455)	50 (345)	40 (276)	25 (172)
Fully grouted	106 (731)	80 (552)	64 (441)	40 (276)
Parallel to bed joints in masonry not laid in running bond				
Continuous grout section parallel to bed joints	133 (917)	133 (917)	133 (917)	133 (917)
Other	0 (0)	0 (0)	0 (0)	0 (0)

For partially grouted masonry, allowable stresses shall be determined on the basis of linear interpolation between fully grouted hollow units and ungrouted hollow units based on amount (percentage) of grouting.

Masonry Construction 9 Lecture 28 Foundations Structures ARCH 331 F2008abr

Allowable Masonry Stresses

- flexure
 - $-F_b = 1/3 f'_m$ (unreinforced)
 - $-F_b = 0.45 \, f_m$ (reinforced)
- shear, unreinforced masonry
 - $-F_{v} = 15$ ≤ 120 psi
- shear, reinforced masonry

– M/Vd ≤ 0.25:

 $F_{v} = 3$

- M/Vd > 1.0:

 $F_v =$

Masonry Construction 11 Lecture 28 Architectural Structures

Allowable Reinforcement Stress

- tension
 - a) Grade 40 or 50 $F_s = 20 \text{ ksi}$
 - $F_s = 32 \text{ ksi}$ b) Grade 60
 - $F_s = 30 \text{ ksi}$ c) Wire joint
- *no allowed increase by 1/3 for combinations with wind & earthquake


- did before 2011 MSJC code

Masonry Construction 12 Lecture 28

Foundations Structures ARCH 331

F2008abn

Reinforcement, M_m




if f_s=F_s (allowable) the moment capacity is limited by the steel

$$MSJC F_b = 0.33f'_m$$

Masonry Construction 15 Architectural Structures III F2010abn

Reinforcement, M_s



$$\label{eq:sigma_smooth} \text{SM about } \text{C}_{\text{m}}\text{:}\quad M_{\text{s}} = A_{\text{s}}f_{\text{s}}jd = \rho bd^{2}jf_{\text{s}}$$

if f_s=F_s (allowable) the moment capacity is limited by the steel

MSJC: $F_s = 20$ ksi, 32 ksi or 30 ksi by type


Masonry Construction 14 Lecture 23

Architectural Structures III

F2010abn


Masonry Lintels


- distributed load
 - triangular or trapezoidal



Masonry Construction 14 Lecture 28

Foundations Structures ARCH 331







F2008abr

Lecture 23

Strategy for RM Flexural Design

- to size section and find reinforcement
 - find ρ_b knowing f_m and f_v
 - size section for some $\rho < \rho_h$
 - get k, j $bd^2 = \frac{M}{}$ • get b & d in nice units

needs to be sized for shear also

- size reinforcement (bar size & #): $A_s = \frac{M}{F_s id}$
- check design: $M_s = A_s F_s jd > M$ $f_b = \frac{M}{0.5bd^2 jk} < F_b$

Masonry Construction 15 Lecture 28

Masonry Construction 17


Lecture 28

Foundations Structures

F2008abn

Masonry Columns and Pilasters

must be reinforced




Foundations Structures

ARCH 331

F2008abn

Ultimate Strength Design

- LRFD
- like reinforced concrete
- useful when beam shear is high
- improved inelastic model
 - ex. earthquake loads



Masonry Construction 16

Foundations Structures

F2008abn

Masonry Columns and Pilasters

- considered a column when b/t < 3 and h/t > 4
 - b is width of "wall"
 - t is thickness of "wall"
- slender is
 - 8" one side
 - h/t ≤ 25
- needs ties
- · eccentricity may be required



Masonry Construction 18 Lecture 28

Foundations Structures ARCH 331

Masonry Columns

- allowable axial load

$$P_{a} = \begin{bmatrix} 0.25 f'_{m} A_{n} + 0.65 A_{st} F_{s} \end{bmatrix} 1 - \left(\frac{h}{140r} \right)^{2}$$

$$h/r \le 99$$

$$P_{a} = \left[0.25 f'_{m} A_{n} + 0.65 A_{st} F_{s}\right] \left(\frac{70r}{h}\right)^{2}$$

$$h/r > 99$$

h = effective length

r = radius of gyration

 A_n = effective area of masonry

 A_{st} = effective area of column reinforcement

 F_s = allowable compressive stress in column reinforcement

Masonry Construction 21 Lecture 24 Foundations Structures ARCH 331 F2011abn

F2008abr

Design

Masonry Construction 21

Lecture 28

masonry columns and walls (unreinforced)

$$\begin{split} \frac{f_a}{F_a} + \frac{f_b}{F_b} &\leq 1.0 \quad \text{and} \quad f_b - f_a \leq F_t \\ - h/r &< 99 \qquad F_a = 0.25 f_m' \bigg[1 - \bigg(\frac{h}{140 r} \bigg)^2 \bigg] \\ - h/r &> 99 \qquad F_a = 0.25 f_m' \bigg(\frac{70 r}{h} \bigg)^2 \\ F_b &= 0.33 f_m' \end{split}$$

Foundations Structures


ARCH 331

Masonry Walls (unreinforced)

- allowable axial stresses

$$F_{a} = 0.25 f'_{m} \left[1 - \left(\frac{h}{140r} \right)^{2} \right] \qquad F_{a} = 0.25 f'_{m} \left(\frac{70r}{h} \right)^{2}$$


$$h/r \le 99 \qquad \qquad h/r > 99$$



Masonry Construction 20 Lecture 28 Foundations Structures ARCH 331 F2008abn

Design

masonry columns and walls - loading




Design

· masonry columns and walls - with rebar

 wall reinforcement usually at center and ineffective in compression

$$f_a + f_b \leq F_b \quad \textit{provided} \quad f_a \leq F_a$$
 Bending stress axial stress



for equilibrium: $\sum F = P = C_m - T_s$


Masonry Construction 23 Lecture 28 Foundations Structures ARCH 331 F2008abn

Final Exam Material

- my list:
 - systems
 - · components & levels
 - · design considerations
 - equilibrium ΣF & ΣM
 - supports, trusses, cables, beams, pinned frames, rigid frames
 - materials
 - strain & stress (E), temperature, constraints

Design Steps Knowing Loads

- 1. assume limiting stress
 - buckling, axial stress, combined stress
- 2. solve for r, A or S
- 3. pick trial section
- 4. analyze stresses
- 5. section ok?
- 6. stop when section is ok



Masonry Construction 24 Lecture 28 Foundations Structures ARCH 331 F2008abn

Final Exam Material

- my list (continued):
 - beams
 - distributed loads, tributary width, V&M, stresses, design, section properties (I & S), pitch, deflection
 - columns
 - stresses, design, section properties (I & r)
 - frames
 - P, V & M, P-∆, effective length with joint stiffness, connection design, tension member design

Masonry Construction 27 Lecture 28 Foundations Structures ARCH 331

Final Exam Material

- my list (continued):
 - foundations
 - types
 - sizing & structural design
 - overturning and sliding
 - design specifics
 - steel (ASD & LRFD)
 - concrete
 - wood
 - masonry

Masonry Construction 28 Lecture 28 Foundations Structures ARCH 331