


*ELEMENTS OF ARCHITECTURAL STRUCTURES:
FORM, BEHAVIOR, AND DESIGN*

ARCH 614

DR. ANNE NICHOLS

SPRING 2013

*lecture
twelve*



*design methods,
structural codes*

Design


- *factors out of the designer's control*
 - *loads*
 - *occurrence*
- *factors within the designer's control*
 - *choice of material*
 - *“cost” of failure (F.S., probability, location)*
 - *economic design method*
 - *analysis method*

Design Methods

- *different approaches to meeting strength/safety requirements*
 - *allowable stress design (elastic)*
 - *ultimate strength design*
 - *limit state design*
 - *plastic design*
 - *load and resistance factor design*
- *assume a behavior at failure or other threshold and include a margin of safety*

Load Types

- D = dead load
- L = live load
- L_r = live roof load
- W = wind load
- S = snow load
- E = earthquake load
- R = rainwater load or ice water load
- T = effect of material & temperature
- H = hydraulic loads from soil (F from fluids)



Weight of Materials

- for a volume

- $W = \gamma V$ where γ is weight/volume


- $W = \gamma t A$ for an extruded area with height of t

LOAD SOURCES

153

TABLE 4.1 Weight of Building Construction

	psf ^a	kPa ^a
<i>Roofs</i>		
3-ply ready roofing (roll, composition)	1	0.05
3-ply felt and gravel	5.5	0.26
5-ply felt and gravel	6.5	0.31
Shingles: Wood	2	0.10
Asphalt	2–3	0.10–0.15
Clay tile	9–12	0.43–0.58
Concrete tile	6–10	0.29–0.48
Slate, 3 in.	10	0.48



Building Codes

- *documentation*
 - *laws that deal with planning, design, construction, and use of buildings*
 - *regulate building construction for*
 - *fire, structural and health safety*
 - *cover all aspect of building design*
 - *references standards*
 - *acceptable minimum criteria*
 - *material & structural codes*


Building Codes

- *occupancy*
- *construction types*
- *structural chapters*
 - *loads, tests, foundations*
- *structural materials, assemblies*
 - *roofs*
 - *concrete*
 - *masonry*
 - *steel*

OCCUPANCY OR USE	UNIFORM (psf)	CONCENTRATED (lbs.)
1. Apartments (see residential)	—	—
2. Access floor systems		
Office use	50	2,000
Computer use	100	2,000
3. Armories and drill rooms	150	—
4. Assembly areas and theaters		
Fixed seats (fastened to floor)	60	
Lobbies	100	
Movable seats	100	—
Stages and platforms	125	
Follow spot, projections and control rooms	50	
Catwalks	40	

Prescribed Loads

- **ASCE-7**
 - *live load (not roof) reductions allowed*
- **International Building Code**
 - *occupancy*
 - *wind: pressure to static load*
 - *seismic: shear load function of mass and response to acceleration*
 - *fire resistance*



Code Reduction of Live Loads

- for (ordinary) live loads
 - factored area supported $\geq 400 \text{ ft}^2$
 - reduction can't exceed
 - $0.5L_o$ (one floor) or $0.4L_o$ (more)

$$L = L_o \left(0.25 + \frac{15}{\sqrt{K_{LL} A_T}} \right)$$

- for live loads $> 100 \text{ lb/ft}^2$
 - live load reduction of 20% on columns
- for (ordinary) roofs: $L_r = L_o R_1 R_2$
 - $12 \text{ lb/ft}^2 \leq L_r \leq 20 \text{ lb/ft}^2$

**TABLE 1607.10.1
LIVE LOAD ELEMENT FACTOR, K_{LL}**

ELEMENT	K_{LL}
Interior columns	4
Exterior columns without cantilever slabs	4
Edge columns with cantilever slabs	3
Corner columns with cantilever slabs	2
Edge beams without cantilever slabs	2
Interior beams	2
All other members not identified above including: Edge beams with cantilever slabs Cantilever beams One-way slabs Two-way slabs Members without provisions for continuous shear transfer normal to their span	1

Structural Codes

- *prescribe loads and combinations*
- *prescribe design method*
- *prescribe stress and deflection limits*
- *backed by the profession*
- *may require design to meet performance standards*
- *related to material or function*

Structural Codes

- *Design Codes*

- *Wood*

- *NDS*

- *Steel*

- *AISC*




- *Concrete*

- *ACI*

- *AASHTO*


- *Masonry*

- *MSJC*



Design Methods

- *probability of loads and resistance*
- *material variability*
- *overload, fracture, fatigue, failure*
- *allowable stress design*




$$f_{actual} = \frac{P}{A} \leq f_{allowed} = \frac{f_{capacity}}{F.S.}$$

- *limit state design*
 - *design loads & capacities*

Allowable Stress Design

- *historical method*
- *a.k.a. working stress, strength design*
- *stresses stay in ELASTIC range*



ASD Load Combinations

- D
- $D + L$
- $D + (L_r \text{ or } S \text{ or } R)$
- $D + 0.75L + 0.75(L_r \text{ or } S \text{ or } R)$
- $D + (0.6W \text{ or } 0.7E)$
- $D + 0.75L + 0.75(0.6W \text{ or } 0.7E) +$
 $(0.75L_r \text{ or } S \text{ or } R)$
- $0.6D + (0.6W \text{ or } 0.7E)$

Limit State Design

- *a.k.a. strength design*
- *stresses go to limit (strain outside elastic range)*
- *loads may be factored*
- *resistance or capacity reduced by a factor*
- *based on material behavior*
- *“state of the art”*

Limit State Design

- *load and resistance factor design (LRFD)*

- *loads:*

- *not constant,*
- *possibly more influential on failure*
- *happen more or less often*

- **UNCERTAINTY**

$$\gamma_D R_D + \gamma_L R_L \leq \phi R_n$$

ϕ - *Resistance factor*


γ - *Load factor for (D)ead & (L)ive load*

LRFD Load Combinations


- $1.4D$
- $1.2D + 1.6L + 0.5(L_r \text{ or } S \text{ or } R)$
- $1.2D + 1.6(L_r \text{ or } S \text{ or } R) + (L \text{ or } 0.5W)$
- $1.2D + 1.0W + L + 0.5(L_r \text{ or } S \text{ or } R)$
- $1.2D + 1.0E + L + 0.2S$
- $0.9D + 1.0W$
- $0.9D + 1.0E$
 - F has same factor as D in 1-5 and 7
 - H adds with 1.6 and resists with 0.9 (permanent)

Load Tracing

- *how loads are transferred*
 - *usually starts at top*
 - *distributed by supports as actions*
 - *distributed by tributary areas*




Load Tracing




Load Tracing

- *tributary load*
 - *think of water flow*
 - “*concentrates*” *load of area into center*


$$w = \left(\frac{\text{load}}{\text{area}} \right) \times (\text{tributary width})$$




Load Paths




(a) FBD—decking.




(b) FBD—joists.




(c) FBD—beams.




(d) FBD—girder.



(a)



(c)



Load Paths

- *wall systems*




Figure 4.12 Uniform wall load from a slab.




Figure 4.13 Uniform wall load from rafters and joists.




Figure 4.14 Concentrated loads from widely spaced beams.

Load Paths

- openings & pilasters




Figure 4.15 Arching over wall openings.




Figure 4.16 Stud wall with a window opening.




Figure 4.17 Pilasters supporting concentrated beam loads.

Load Paths

- foundations




Figure 4.24 Spread footing.




Figure 4.25 Wall footing.




Figure 4.26 Mat or raft foundation.

Load Paths

- *deep foundations*




Figure 4.27 Pile foundations.




Figure 4.28 Pile cap on one pile group.




Figure 4.29 Grade beam supporting a bearing wall.