

ELEMENTS OF ARCHITECTURAL STRUCTURES:
FORM, BEHAVIOR, AND DESIGN

ARCH 614

DR. ANNE NICHOLS

SPRING 2013

lecture
sixteen

steel construction:
materials & beams




Steel Beams 1
Lecture 16

Elements of Architectural Structures
ARCH 614

S2009abn

Steel Beam Design

- American Institute of Steel Construction
 - Manual of Steel Construction
 - ASD & LRFD
 - combined in 2005




Steel Beams 2
Lecture 16

Elements of Architectural Structures
ARCH 614

S2007abn

Steel Materials

- steel grades
 - ASTM A36 – carbon
 - plates, angles
 - $F_y = 36 \text{ ksi}$ & $F_u = 58 \text{ ksi}$
 - ASTM A572 – high strength low-alloy
 - some beams
 - $F_y = 60 \text{ ksi}$ & $F_u = 75 \text{ ksi}$
 - ASTM A992 – for building framing
 - most beams
 - $F_y = 50 \text{ ksi}$ & $F_u = 65 \text{ ksi}$






Steel Beams 3
Lecture 16

Elements of Architectural Structures
ARCH 614

S2007abn

Steel Properties

- high strength to weight ratio
- elastic limit – yield (F_y)
- inelastic – plastic
- ultimate strength (F_u)
- ductile
- strength sensitive to temperature
- can corrode
- fatigue




Winnipeg DOT
S2007abn

Steel Beams 4
Lecture 16

Elements of Architectural Structures
ARCH 614

LRFD

- loads on structures are
 - not constant
 - can be more influential on failure
 - happen more or less often
 - **UNCERTAINTY**





$$R_u = \gamma_D R_D + \gamma_L R_L \leq \phi R_n$$

ϕ - resistance factor

γ - load factor for (D)ead & (L)ive load

LRFD Steel Beam Design

- limit state is yielding all across section
- outside elastic range
- load factors & resistance factors




LRFD Load Combinations

ASCE-7
(2010)

- 1.4D
- 1.2D + 1.6L + 0.5(L_r or S or R)
- 1.2D + 1.6(L_r or S or R) + (L or 0.5W)
- 1.2D + 1.0W + L + 0.5(L_r or S or R)
- 1.2D + 1.0E + L + 0.2S
- 0.9D + 1.0W
- 0.9D + 1.0E
 - F has same factor as D in 1-5 and 7
 - H adds with 1.6 and resists with 0.9 (permanent)



Beam Design Criteria (revisited)

- strength design
 - bending stresses predominate
 - shear stresses occur
- serviceability
 - limit deflection
 - stability
- superpositioning
 - use of beam charts
 - elastic range only!
 - “add” moment diagrams
 - “add” deflection CURVES (not maximums)



Steel Beams

- lateral stability - bracing
- local buckling – stiffen, or bigger I_y



Steel Beams 13
Lecture 16

Elements of Architectural Structures
ARCH 614

S2007abn

Local Buckling

- flange
- web




Figure 2-5. Flange Local Bending Limit State
(Beedle, L.S., Christopher, R., 1964)



Figure 2-7. Web Local Buckling Limit State
(SAC Project)


Steel Beams 15
Lecture 16

Elements of Architectural Structures
ARCH 614

S2007abn

Local Buckling

- steel I beams
- flange
 - buckle in direction of smaller radius of gyration
- web
 - force
 - “crippling”




Steel Beams 14
Lecture 16

Elements of Architectural Structures
ARCH 614

S2007abn

Shear in Web

- panels in plate girders or webs with large shear
- buckling in compression direction
- add stiffeners



Steel Beams 16
Lecture 16

Elements of Architectural Structures
ARCH 614

S2007abn

Shear in Web

- plate girders and stiffeners



Steel Beams 17
Lecture 16

Elements of Architectural Structures
ARCH 614

<http://nisee.berkeley.edu/godden>

S2010abn

Steel Beams

- bearing
 - provide adequate area
 - prevent local yield of flange and web




Figure 9.10 Considerations for bearing in beams with thin webs, as related to web crippling (buckling of the thin web in compression).

Steel Beams 18
Lecture 16

Elements of Architectural Structures
ARCH 614

S2010abn

LRFD - Flexure

$$\sum \gamma_i R_i = M_u \leq \phi_b M_n = 0.9 F_y Z$$

M_u - maximum moment

ϕ_b - resistance factor for bending = 0.9

M_n - nominal moment (ultimate capacity)


F_y - yield strength of the steel

Z - plastic section modulus*

Internal Moments - at yield

- material hasn't failed

$$M_y = \frac{I}{c} f_y = \frac{bh^2}{6} f_y$$



$$= \frac{b(2c)^2}{6} f_y = \frac{2bc^2}{3} f_y$$

Steel Beams 18
Lecture 16

Elements of Architectural Structures
ARCH 614

S2007abn


Steel Beams 19
Lecture 16

Elements of Architectural Structures
ARCH 614


S2007abn

Internal Moments - ALL at yield

- all parts reach yield
- plastic hinge forms
- ultimate moment
- $A_{tension} = A_{compression}$




$$M_p = bc^2 f_y = \frac{3}{2} M_y$$




n.a. of Section at Plastic Hinge

- cannot guarantee at centroid
- $f_y \cdot A_1 = f_y \cdot A_2$
- moment found from yield stress times moment area




$$M_p = f_y A_1 d = f_y \sum_{n.a} A_i d_i$$

Plastic Hinge Development



Plastic Hinge Examples

- stability can be effected



Plastic Section Modulus

- shape factor, k

$$k = \frac{M_p}{M_y}$$

= 3/2 for a rectangle

≈ 1.1 for an I



$$k = \frac{Z}{S}$$

- plastic modulus, Z

$$Z = \frac{M_p}{f_y}$$

LRFD - Flexure Design

- limit states for beam failure

1. yielding

2. lateral-torsional buckling^R

3. flange local buckling

4. web local buckling

- minimum M_n governs

$$L_p = 1.76 r_y \sqrt{\frac{F_y}{E}}$$

$$\Sigma \gamma_i R_i = M_u \leq \phi_b M_n$$

LRFD - Shear

$$\Sigma \gamma_i R_i = V_u \leq \phi_v V_n = 1.0 (0.6 F_{yw} A_w)$$

V_u - maximum shear

ϕ_v - resistance factor for shear = 0.9

V_n - nominal shear

F_{yw} - yield strength of the steel in the web

A_w - area of the web = $t_w d$

Compact Sections


- plastic moment can form before any buckling

- criteria

$$-\frac{b_f}{2t_f} \leq 0.38 \sqrt{\frac{E}{F_y}}$$

$$-\text{and } \frac{h_c}{t_w} \leq 3.76 \sqrt{\frac{E}{F_y}}$$

TABLE A.3 Properties of W Shapes



Lateral Torsional Buckling

$$M_n = C_b \left[\begin{array}{l} \text{moment based on} \\ \text{lateral buckling} \end{array} \right] \leq M_p$$

$$C_b = \frac{12.5M_{\max}}{2.5M_{\max} + 2M_A + 4M_B + 3M_C}$$

C_b = modification factor

M_{\max} - |max moment|, unbraced segment

M_A - |moment|, 1/4 point

M_B = |moment|, center point


M_C = |moment|, 3/4 point

Steel Beams 28
Lecture 16

Elements of Architectural Structures
ARCH 614

S2007abn

Beam Design Charts



Steel Beams :
Lecture 16

S2012abn

Charts & Deflections

- beam charts
 - solid line is most economical
 - dashed indicates there is another more economical section
 - self weight is NOT included in M_n
- deflections
 - no factors are applied to the loads
 - often governs the design

Design Procedure (revisited)

1. Know unbraced length, material, design method (Ω , ϕ)
2. Draw V & M, finding M_{\max}
3. Calculate $Z_{\text{req'd}}$ ($f_b \leq F_b$)
($M_u \leq \phi_b M_n$)
4. Choose (economical) section from section or beam capacity charts

Steel Beams 30
Lecture 16

Elements of Architectural Structures
ARCH 614

S2007abn

Steel Beams 31
Lecture 16

Elements of Architectural Structures
ARCH 614

S2009abn

Beam Charts by Z_x (pg. 250)

TABLE 9.1 Load Factor Resistance Design Selection for Shapes Used as Beams

Designation	Z_x in. ³	$F_y = 36$ ksi				$F_y = 50$ ksi				r_x in.	$b_f/2t_f$	h/t_w	X_1 ksi	$X_2 \times 10^6$ (1/ksi) ²
		L_p ft	L_r ft	M_p kip-ft	M_r kip-ft	L_p ft	L_r ft	M_p kip-ft	M_r kip-ft					
W 33 x 141	514	10.1	30.1	1,542	971	8.59	23.1	2,142	1,493	2.43	6.01	49.6	1,800	17,800
W 30 x 148	500	9.50	30.6	1,500	945	8.06	22.8	2,083	1,453	2.28	4.44	41.6	2,310	6,270
W 24 x 162	468	12.7	45.2	1,404	897	10.8	32.4	1,950	1,380	3.05	5.31	30.6	2,870	2,260
W 24 x 146	418	12.5	42.0	1,254	804	10.6	30.6	1,742	1,237	3.01	5.92	33.2	2,590	3,420
W 33 x 118	415	9.67	27.8	1,245	778	8.20	21.7	1,729	1,197	2.32	7.76	54.5	1,510	37,700
W 30 x 124	408	9.29	28.2	1,224	769	7.88	21.5	1,700	1,183	2.23	5.65	46.2	1,930	13,500
W 21 x 147	373	12.3	46.4	1,119	713	10.4	32.8	1,554	1,097	2.95	5.44	26.1	3,140	1,590
W 24 x 131	370	12.4	39.3	1,110	713	10.5	29.1	1,542	1,097	2.97	6.70	35.6	2,330	5,290
W 18 x 158	356	11.4	56.5	1,068	672	9.69	38.0	1,483	1,033	2.74	3.92	19.8	4,410	403
W 30 x 108	346	8.96	26.3	1,038	648	7.60	20.3	1,442	997	2.15	6.89	49.6	1,680	24,200
W 27 x 114	343	9.08	28.2	1,029	648	7.71	21.3	1,429	997	2.18	5.41	42.5	2,100	9,220
W 24 x 117	327	12.3	37.1	981	631	10.4	27.9	1,363	970	2.94	7.53	39.2	2,090	8,190
W 21 x 122	307	12.2	41.0	921	592	10.3	29.8	1,279	910	2.92	6.45	31.3	2,630	3,160
W 18 x 130	290	11.3	47.7	870	555	9.55	32.8	1,208	853	2.7	4.65	23.9	3,680	810
W 30 x 90	283	8.71	24.8	849	531	7.39	19.4	1,179	817	2.09	8.52	57.5	1,410	49,600
W 24 x 103	280	8.29	27.0	840	531	7.04	20.0	1,167	817	1.99	4.59	39.2	2,390	5,310
W 27 x 94	278	8.83	25.9	834	527	7.50	19.9	1,158	810	2.12	6.70	49.5	1,740	19,900
W 14 x 145	260	16.6	81.6	780	503	14.1	54.7	1,083	773	3.98	7.11	16.8	4,400	348
W 24 x 94	254	8.25	25.9	762	481	7.00	19.4	1,058	740	1.98	5.18	41.9	2,180	7,800

Beam Design (revisited)

6. Evaluate shear stresses - horizontal

- $(f_v \leq F_v)$ or $(V_u \leq \phi_v V_n)$
- W and rectangles $f_{v-max} = \frac{3V}{2A} \approx \frac{V}{A_{web}}$
- thin walled sections $f_{v-max} = \frac{VQ}{Ib}$

Beam Design (revisited)


4*. Include self weight for M_{max}

- and repeat 3 & 4 if necessary

5. Consider lateral stability

Unbraced roof trusses were blown down in 1999 at this project in Moscow, Idaho.


Photo: Ken Carper



Beam Design (revisited)

7. Provide adequate bearing area at supports

$$f_p = \frac{P}{A} \leq F_p$$



Beam Design (revisited)

8. Evaluate torsion

$$(f_v \leq F_v)$$

- circular cross section

$$f_v = \frac{T\rho}{J}$$

- rectangular

$$f_v = \frac{T}{c_1 ab^2}$$





TABLE 3.1. Coefficients for Rectangular Bars in Torsion

a/b	c ₁	c ₂
1.0	0.208	0.1406
1.2	0.219	0.1661
1.5	0.231	0.1958
2.0	0.246	0.229
2.5	0.258	0.249
3.0	0.267	0.263
4.0	0.282	0.281
5.0	0.291	0.291
10.0	0.312	0.312
∞	0.333	0.333

Beam Design (revisited)

9. Evaluate deflections – NO LOAD FACTORS



$$y_{max}(x) = \Delta_{actual} \leq \Delta_{allowable}$$

Load Tables & Equivalent Load

- uniformly distributed loads
- equivalent “w”

$$M_{max} = \frac{w_{equivalent} L^2}{8}$$

LRFD


STANDARD LOAD TABLE FOR OPEN WEB STEEL JOISTS, K-SERIES
Based on a 50 ksi Maximum Yield Strength - Loads Shown in Pounds per Linear Foot (plf)

Joist Designation	8K1	10K1	12K1	12K3	12K5	14K1	14K3	14K4	14K6	16K2	16K3	16K4	16K5	16K6	16K7	16K9
Depth (in.)	8	10	12	12	12	14	14	14	14	16	16	16	16	16	16	16
Approx. Wt (lb./ft.)	5.1	5.0	5.0	5.7	7.1	5.2	6.0	6.7	7.7	5.5	6.3	7.0	7.5	8.1	8.6	10.0
Span (ft.)																
8	805	825														
9	825	850														
10	850	875														
11	875	900														
12	900	925	805	825	850											
13	925	950	825	850	875											
14	950	975	850	875	900	805	825	850	875							
15	975	1000	875	900	925	825	850	875	900	805	825	850	875	900	925	950
16	1000	1025	900	925	950	850	875	900	925	825	850	875	900	925	950	975
17	1025	1050	925	950	975	875	900	925	950	850	875	900	925	950	975	1000
18	1050	1075	950	975	1000	890	915	940	965	875	900	925	950	975	1000	1025
19	1075	1100	975	1000	1025	915	940	965	990	890	915	940	965	990	1015	1040
20	1100	1125	1000	1025	1050	940	965	990	1015	915	940	965	990	1015	1040	1065
21	1125	1150	1025	1050	1075	965	990	1015	1040	940	965	990	1015	1040	1065	1090
22	1150	1175	1050	1075	1100	990	1015	1040	1065	965	990	1015	1040	1065	1090	1115
23	1175	1200	1075	1100	1125	1015	1040	1065	1090	990	1015	1040	1065	1090	1115	1140

load for live load deflection limit
in RED, total in BLACK

Steel Arches and Frames

- solid sections
- or open web



<http://nisee.berkeley.edu/godden>

Steel Shell and Cable Structures




TOPIC 39

Elements of Architectural Structures
ARCH 614

S2009abn

Approximate Depths



TOPIC 4

S2009abn