


lecture  
twelve



# design methods, structural codes

## Design Methods

- different approaches to meeting strength/safety requirements
  - allowable stress design (elastic)
  - ultimate strength design
  - limit state design
  - plastic design
  - load and resistance factor design
- assume a behavior at failure or other threshold and include a margin of safety

## Design

- factors out of the designer's control
  - loads
  - occurrence
- factors within the designer's control
  - choice of material
  - “cost” of failure (F.S., probability, location)
  - economic design method
  - analysis method

## Load Types

- $D$  = dead load
- $L$  = live load
- $L_r$  = live roof load
- $W$  = wind load
- $S$  = snow load
- $E$  = earthquake load
- $R$  = rainwater load or ice water load
- $T$  = effect of material & temperature
- $H$  = hydraulic loads from soil ( $F$  from fluids)




Figure 1.13 Wind loads on a structure.

## Weight of Materials


- for a volume
  - $W = \gamma V$  where  $\gamma$  is weight/volume
  - $W = \gamma t A$  for an extruded area with height of  $t$

LOAD SOURCES

153

TABLE 4.1 Weight of Building Construction

	psf <sup>a</sup>	kPa <sup>a</sup>
<i>Roofs</i>		
3-ply ready roofing (roll, composition)	1	0.05
3-ply felt and gravel	5.5	0.26
5-ply felt and gravel	6.5	0.31
Shingles: Wood	2	0.10
Asphalt	2-3	0.10-0.15
Clay tile	9-12	0.43-0.58
Concrete tile	6-10	0.29-0.48
Slate, 3 in.	10	0.48



Methods & Codes 5  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2007abn

## Building Codes

- documentation
  - laws that deal with planning, design, construction, and use of buildings
  - regulate building construction for
    - fire, structural and health safety
  - cover all aspect of building design
  - references standards
    - acceptable minimum criteria
    - material & structural codes

Methods & Codes 6  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2007abn

## Building Codes

- occupancy
- construction types
- structural chapters
  - loads, tests, foundations
- structural materials, assemblies
  - roofs
  - concrete
  - masonry
  - steel

OCCUPANCY OR USE	UNIFORM (psf)	CONCENTRATED (lbs.)
1. Apartments (see residential)	—	—
2. Access floor systems		
Office use	50	2,000
Computer use	100	2,000
3. Anatomies and drill rooms	150	—
4. Assembly areas and theaters		
Fixed seats (fastened to floor)	60	—
Lobbies	100	—
Movable seats	100	—
Stages and platforms	125	—
Follow spot, projections and control rooms	50	—
Catwalks	40	—

Methods & Codes 7  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2007abn

## Prescribed Loads

- ASCE-7
  - live load (not roof) reductions allowed
- International Building Code
  - occupancy
  - wind: pressure to static load
  - seismic: shear load function of mass and response to acceleration
  - fire resistance




Figure 1.14 Earthquake loads on a structure.

Methods & Codes 8  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2007abn

## Code Reduction of Live Loads

- for (ordinary) live loads
  - factored area supported  $\geq 400 \text{ ft}^2$
  - reduction can't exceed
    - $0.5L_o$  (one floor) or  $0.4L_o$  (more)

$$L = L_o \left( 0.25 + \frac{15}{\sqrt{K_{LL} A_T}} \right)$$

- for live loads  $> 100 \text{ lb/ft}^2$ 
  - live load reduction of 20% on columns
- for (ordinary) roofs:  $L_r = L_o R_1 R_2$ 
  - $12 \text{ lb/ft}^2 \leq L_r \leq 20 \text{ lb/ft}^2$

TABLE 1607.10.1  
LIVE LOAD ELEMENT FACTOR,  $K_{LL}$

ELEMENT	$K_{LL}$
Interior columns	4
Exterior columns without cantilever slabs	4
Edge columns with cantilever slabs	3
Corner columns with cantilever slabs	2
Edge beams without cantilever slabs	2
Interior beams	2
All other members not identified above including: Edge beams with cantilever slabs Cantilever beams One-way slabs Two-way slabs Members without provisions for continuous shear transfer normal to their span	1




Methods & Codes 9  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2013abn

## Structural Codes

- Design Codes
  - Wood
    - NDS
  - Steel
    - AISC
  - Concrete
    - ACI
    - AASHTO
  - Masonry
    - MSJC



Methods & Codes 9  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2007abn

## Structural Codes

- prescribe loads and combinations
- prescribe design method
- prescribe stress and deflection limits
- backed by the profession
- may require design to meet performance standards
- related to material or function


Methods & Codes 8  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2007abn

## Design Methods

- probability of loads and resistance
- material variability
- overload, fracture, fatigue, failure
- allowable stress design



$$f_{actual} = \frac{P}{A} \leq f_{allowed} = \frac{f_{capacity}}{F.S.}$$

- limit state design
  - design loads & capacities

Methods & Codes 10  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2007abn

## Allowable Stress Design

- historical method
- a.k.a. working stress, strength design
- stresses stay in ELASTIC range




Figure 5.20 Stress-strain diagram for various materials.

## ASD Load Combinations

ASCE-7  
(2010)

- $D$
- $D + L$
- $D + (L_r \text{ or } S \text{ or } R)$
- $D + 0.75L + 0.75(L_r \text{ or } S \text{ or } R)$
- $D + (0.6W \text{ or } 0.7E)$
- $D + 0.75L + 0.75(0.6W \text{ or } 0.7E) + (0.75L_r \text{ or } S \text{ or } R)$
- $0.6D + (0.6W \text{ or } 0.7E)$

## Limit State Design

- a.k.a. strength design
- stresses go to limit (strain outside elastic range)
- loads may be factored
- resistance or capacity reduced by a factor
- based on material behavior
- “state of the art”

## Limit State Design

- load and resistance factor design (LRFD)
  - loads:
    - not constant,
    - possibly more influential on failure
    - happen more or less often
  - UNCERTAINTY

$$\gamma_D P_D + \gamma_L P_L \leq \phi P_u$$

$\phi$  - Resistance factor

$\gamma$  - Load factor for (D)ead & (L)ive load

# LRFD Load Combinations

ASCE-7  
(2010)


- 1.4D
- 1.2D + 1.6L + 0.5(L<sub>r</sub> or S or R)
- 1.2D + 1.6(L<sub>r</sub> or S or R) + (L or 0.5W)
- 1.2D + 1.0W + L + 0.5(L<sub>r</sub> or S or R)
- 1.2D + 1.0E + L + 0.2S
- 0.9D + 1.0W
- 0.9D + 1.0E
  - F has same factor as D in 1-5 and 7
  - H adds with 1.6 and resists with 0.9 (permanent)

Methods & Codes 17  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2013abn

# Load Tracing




Methods & Codes 17  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2007abn

# Load Tracing

- how loads are transferred
  - usually starts at top
  - distributed by supports as actions
  - distributed by tributary areas



Methods & Codes 16  
Lecture 12


Elements of Architectural Structures  
ARCH 614

S2007abn

# Load Tracing

- tributary load
  - think of water flow
  - “concentrates” load of area into center

$$w = \left( \frac{\text{load}}{\text{area}} \right) \times (\text{tributary width})$$




Methods & Codes 18  
Lecture 12


Elements of Architectural Structures  
ARCH 614

S2007abn


# Load Paths




(a) FBD—decking.






(b) FBD—joists.



(c) FBD—beams.



(d) FBD—girder.



Methods & Codes 19  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2007abn

# Load Paths

- wall systems




Figure 4.12 Uniform wall load from a slab.




Figure 4.13 Uniform wall load from rafters and joists.




Figure 4.14 Concentrated loads from widely spaced beams.

Methods & Codes 20  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2007abn

# Load Paths

- openings & pilasters




Figure 4.15 Arching over wall openings.




Figure 4.16 Stud wall with a window opening.




Figure 4.17 Pilasters supporting concentrated beam loads.

Methods & Codes 21  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2007abn

# Load Paths

- foundations




Figure 4.24 Spread footing.




Figure 4.25 Wall footing.




Figure 4.26 Mat or raft foundation.

Methods & Codes 22  
Lecture 12

Elements of Architectural Structures  
ARCH 614

S2007abn

# Load Paths

- deep foundations




Figure 4.27 Pile foundations.




Figure 4.28 Pile cap on one pile group.




Figure 4.29 Grade beam supporting a bearing wall.