


lecture three

design codes, building codes




Design & Codes 1
Lecture 3

Applied Architectural Structures
ARCH 631

F2009abn

Structural Requirements

- serviceability
 - strength
 - deflections
- efficiency
 - economy of materials
- construction
- cost
- other



Design & Codes 2
Lecture 3

Architectural Structures III
ARCH 631

F2009abn

Structure Requirements

- strength & equilibrium
 - safety
 - stresses not greater than strength
 - adequate foundation



Figure 1.16 Equilibrium and Stability?—sculpture by Richard Byer. Photo by author.

Design & Codes 3
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Structure Requirements

- stability & stiffness
 - stability of components
 - minimum deflection and vibration
 - adequate foundation



Figure 1.15 Stability and the strength of a structure—the collapse of a portion of the UW Husky stadium during construction (1987) due to a lack of adequate bracing to ensure stability. Photo by author.

Design & Codes 4
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Structure Requirements

- *economy and construction*
 - *minimum material*
 - *standard sized members*
 - *simple connections and details*
 - *maintenance*
 - *fabrication/ erection*



Design & Codes 5
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design Procedure

- *planning*
- *preliminary structural configuration*
- *determination of loads*
- *preliminary member selection*
- *analysis*
- *evaluation*
- *design revision*
- *final design*




Design & Codes 6
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design Procedure

- *planning to establish*
 - *function of structure*
 - *criteria for optimum design*
 - *code jurisdiction*
- *preliminary structural configuration*
 - *arrangement of elements within form*
 - *columns*
 - *beams*
 - *joists*
 - *trusses*




Design & Codes 7
Lecture 3

Architectural Structures III
ARCH 631

S2009abn

Design Procedure

- *determination of loads*
 - *structure weight*
 - *moving loads*
 - *severe, rare loads*
- *preliminary member selection*
 - *based on configuration, determine loads on individual elements*
 - *determine internal forces & stresses*
 - *choose section to satisfy primary strength requirement*




} *building codes*

Design & Codes 8
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design Procedure

- *analysis*
 - *actual structure weight*
 - *with other loads*
 - *based on structural system / modeling*
 - *elements – columns, beams...*
 - *connections*
 - *systems – frames, trusses*
 - *deflections and deformations*
 - *different load combination?*
 - *pattern loading*
- 





Design & Codes 9
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design Procedure

- *evaluation*
 - *measure results against criteria*
 - *strength?*
 - *deflections?*
 - *economy?*
 - *revise design*
 - *any criteria NOT met*
 - *change member sizes, material, arrangement*
- 
- A hand-drawn architectural section drawing of a timber structure. The drawing shows a cross-section of a building with a sloped roof and a vertical wall. The roof is labeled 'grid lines'. The wall is labeled 'SECTION (timber)'. The drawing is on a grid background.




Design & Codes 10
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design Procedure

- *final design*
 - *analyze revised design*
 - *evaluate and meets requirements*
 - *draw structural plan*





Design & Codes 11
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Building Codes

- *documentation*
 - *laws that deal with planning, design, construction, and use of buildings*
 - *regulate building construction for*
 - *fire, structural and health safety*
 - *cover all aspect of building design*
 - *references standards*
 - *acceptable minimum criteria*
 - *material & structural codes*
- 



Design & Codes 12
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Building Codes

- occupancy
- construction types
- structural chapters
 - loads, tests, foundations
- structural materials, assemblies
 - roofs
 - concrete
 - masonry
 - steel

OCCUPANCY OR USE	UNIFORM (psf)	CONCENTRATED (lbs.)
1. Apartments (see residential)	—	—
2. Access floor systems	50	2,000
Office use	100	2,000
Computer use	—	—
3. Armories and drill rooms	150	—
4. Assembly areas and theaters	60	—
Fixed seats (fastened to floor)	100	—
Lobbies	100	—
Movable seats	125	—
Stages and platforms	50	—
Follow spot, projections and control rooms	40	—
Caiswalks	—	—

Building Codes

- adoptable codes
 - Southern Building Code Congress International (SBCCI)
 - Building Officials & Code Administrators International (BOCA)
 - International Conference of Building Officials (UBO)
 - International Building Code (IBC)
 - attempt to get one unified code in 2000



Code Reduction of Live Loads^(ALTERNATIVE)

- now allowed for ordinary roofs
- for live loads $\leq 100 \text{ lb/ft}^2$
 - area supported $\geq 150 \text{ ft}^2$
 - not a garage
 - reduction of $0.08\% / \text{ft}^2$ allowed
 - reduction can't exceed
 - 60% or 40%
- for live loads $> 100 \text{ lb/ft}^2$
 - live load reduction of 20% on columns




Standards

- criteria for quality
 - American National Standards Institute (ANSI)
 - American Society of Testing and Materials (ASTM)
- materials
 - Brick Industry Association (BIA)
 - Portland Cement Association (PCA)
 - National Concrete Masonry Association (NCMA)



Structural Codes

- *prescribe loads and combinations*
- *prescribe design method*
- *prescribe stress and deflection limits*
- *backed by the profession*
- *may require design to meet performance standards*
- *related to material or function*




Design & Codes 17
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Structural Codes

- *American Concrete Institute (ACI)*
- *American Institute of Steel Construction (AISC)*
- *Precast/Prestressed Concrete Institute (PCI)*
- *Post Tensioning Institute (PTI)*
- *Structural Joist Institute (SJI)*
- *National Design Specifications (NDS)*
– *National Forest Products Association*



Design & Codes 18
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design

- *factors out of the designer's control*
 - *loads*
 - *occurrence*
- *factors within the designer's control*
 - *choice of material*
 - *“cost” of failure (F.S., probability, location)*
 - *economic design method*
 - *analysis method*



Design & Codes 19
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design Methods

- *different approaches to meeting strength/safety requirements*
 - *allowable stress design (elastic)*
 - *ultimate strength design*
 - *limit state design*
 - *plastic design*
 - *load and resistance factor design*
- *assume a behavior at failure or other threshold and include a margin of safety*



<http://mceer.buffalo.edu>

Design & Codes 20
Lecture 3


Architectural Structures III
ARCH 631

F2008abn

Design Methods

- structures and connections see

- shear
- bending
- bearing
- axial stress
 - compression
 - tension
- torsion



Design & Codes 21
Lecture 3

Architectural Structures III
ARCH 631

F2009abn

Design Methods

- materials have a critical stress value where they could break or yield

- ultimate stress
- yield stress
- compressive stress
- fatigue strength
- (creep & temperature)

acceptance
vs. failure



Design & Codes 22
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design Methods

- material behavior




Figure 5.22 Stress-strain diagram for mild steel (A36) with key points highlighted.

Design & Codes 23
Lecture 3

Architectural Structures III
ARCH 631

F2008abn


Design Methods

- allowable stress design

- elastic range
- factor of safety (F.S.)

$$f_{actual} = \frac{P}{A} \leq f_{allowed} = \frac{f_{capacity}}{F.S.}$$

- probability of loads and resistance
- material variability
- overload, fracture, fatigue, failure




Design & Codes 24
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design Methods

- *load and resistance factor design (LRFD)*
 - beyond allowable stress
- *materials aren't uniform 100% of the time*
 - ultimate strength or capacity to failure may be different and some strengths hard to test for
- **RISK & UNCERTAINTY**



$$f_u = \frac{P_u}{A}$$


Design & Codes 25
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design Methods

- *loads on structures are*
 - not constant
 - can be more influential on failure
 - happen more or less often
 - **UNCERTAINTY**



$$\gamma_D P_D + \gamma_L P_L \leq \phi P_u$$

ϕ - Resistance factor

γ - Load factor for (D)ead & (L)ive load


Design & Codes 26
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Loads

- *gravity acts on mass ($F=m \cdot g$)*
- *force of mass*
 - acts at a point
 - ie. joist on beam
 - acts along a “line”
 - ie. floor on a beam
 - acts over an area
 - ie. people, books, snow on roof or floor




Design & Codes 27
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Load Tracing

- *how loads are transferred*
 - usually starts at top
 - distributed by supports as actions
 - distributed by tributary areas




Design & Codes 28
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Load Tracing



Design & Codes 29
Lecture 3


Architectural Structures III
ARCH 631

F2008abn

Load Tracing

- tributary load
 - think of water flow
 - “concentrates” load of area into center

$$w = \left(\frac{\text{load}}{\text{area}} \right) \times (\text{tributary width})$$




Design & Codes 30
Lecture 3


Architectural Structures III
ARCH 631

F2008abn


Load Paths




(a) FBD—decking.






(b) FBD—joists.



(c) FBD—beams.



(d) FBD—girder.



Load Paths

- wall systems




Figure 4.12 Uniform wall load from a slab.




Figure 4.13 Uniform wall load from rafters and joists.




Figure 4.14 Concentrated loads from widely spaced beams.

Design & Codes 31
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design & Codes 32
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Load Paths

- openings & pilasters




Figure 4.15 Arching over wall openings.




Figure 4.16 Stud wall with a window opening.




Figure 4.17 Pilasters supporting concentrated beam loads.

Load Paths

- foundations




Figure 4.24 Spread footing.




Figure 4.25 Wall footing.




Figure 4.26 Mat or raft foundation.

Design & Codes 33
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design & Codes 34
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Load Paths

- deep foundations




Figure 4.27 Pile foundations.




Figure 4.28 Pile cap on one pile group.




Figure 4.29 Grade beam supporting a bearing wall.

Load Types

- D = dead load
- L = live load
- L_r = live roof load
- W = wind load
- S = snow load
- E = earthquake load
- R = rainwater load or ice water load
- T = effect of material & temperature
- H = hydraulic loads from soil (F from fluids)




Figure 1.13 Wind loads on a structure.

Design & Codes 35
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

Design & Codes 36
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

ASD Load Combinations

ASCE-7
(2010)

- D
- $D + L$
- $D + (L_r \text{ or } S \text{ or } R)$
- $D + 0.75L + 0.75(L_r \text{ or } S \text{ or } R)$
- $D + (0.6W \text{ or } 0.7E)$
- $D + 0.75L + 0.75(0.6W \text{ or } 0.7E) + (0.75L_r \text{ or } S \text{ or } R)$
- $0.6D + (0.6W \text{ or } 0.7E)$



Design & Codes 37
Lecture 3

Architectural Structures III
ARCH 631

F2008abn

LRFD Load Combinations

ASCE-7
(2010)

- $1.4D$
- $1.2D + 1.6L + 0.5(L_r \text{ or } S \text{ or } R)$
- $1.2D + 1.6(L_r \text{ or } S \text{ or } R) + (L \text{ or } 0.5W)$
- $1.2D + 1.0W + L + 0.5(L_r \text{ or } S \text{ or } R)$
- $1.2D + 1.0E + L + 0.2S$
- $0.9D + 1.0W$
- $0.9D + 1.0E$
 - $0.9D + 1.0E$ F has same factor as D in 1-5 and 7
 - H adds with 1.6 and resists with 0.9 (permanent)



Design & Codes 38
Lecture 3

Architectural Structures III
ARCH 631

F2008abn