

lecture
twenty four



foundations and retaining walls



Bright Football Complex
www.tamu.edu

Foundation

- the engineered interface between the earth and the structure it supports that transmits the loads to the soil or rock




Structural vs. Foundation Design

- structural design
 - choice of materials
 - choice of framing system
 - uniform materials and quality assurance
 - design largely independent of geology, climate, etc.



Structural vs. Foundation Design

- foundation design
 - cannot specify site materials
 - site is usually predetermined
 - framing/structure predetermined
 - site geology influences foundation choice
 - no site the same
 - no design the same




Design Assumptions

- *validity dependant on:*
 - quality of site investigation
 - construction monitoring
 - your experience
 - flexibility of the design


Soil Properties & Mechanics

- *compressibility*
 - settlements
- *strength*
 - stability
 - shallow foundations
 - deep foundations
 - slopes and walls
 - ultimate bearing capacity, q_u
 - allowable bearing capacity, $q_a = \frac{q_u}{S.F.}$



Soil Properties & Mechanics

- *unit weight of soil*
- *allowable soil pressure*
- *factored net soil pressure*
- *shear resistance*
- *backfill pressure*
- *cohesion & friction of soil*
- *effect of water*
- *settlement*
- *rock fracture behavior*



Soil Properties & Mechanics

- *strength, q_a*


Class of material	Loadbearing pressure (pounds per square foot) ^a
1. Crystalline bedrock	12,000
2. Sedimentary rock	6,000
3. Sandy Gravel	5,000
4. Sand, silty sand, clayey sand, silty gravel and clayey gravel	3,000
5. Clay, sandy clay, silty clay & clayey silt	2,000

Note a. 1 psf = 47.9 Pa.

FIGURE 2.5
Presumptive surface bearing values of various soils, as given in the BOCA National Building Code/1996. (Reproduced by permission)

Bearing Failure

- shear




Foundations 9
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Lateral Earth Pressure

- passive vs. active



Foundations 10
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Settlements - Considerations

- How do we estimate the amount for a given design?
- What are the tolerable movements?
- If our estimate is greater than the tolerable movement, what do we do?



www.calculustfoundations.com


Foundations 11
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Settlements - Components

- vertical
 - immediate (sands)
 - consolidation (clays)
 - secondary (organic soils/peats)
- tilting
 - eccentric loads
 - non-uniform stress distribution
- distortion - $\frac{\Delta}{L}$



Foundations 12
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Excessive Settlement

- we can try
 - deeper foundation
 - alter structure
 - concrete/soil mat foundation
 - reduce the load
 - move the structure
 - modify the foundation type
 - modify the soil



Foundations 13
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Foundation Materials

- concrete, plain or reinforced
 - shear
 - bearing capacity
 - bending
 - embedment length, development length
- other materials (piles)
 - steel
 - wood
 - composite



Foundations 14
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Construction

- unique to type of footing
 - excavation
 - sheeting and bracing
 - water control
(drainage/stabilization)
 - fill: placement & compaction
 - pile driver or hammer
 - caisson
 - underpinning (existing foundation)



Foundations 15
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Basic Foundation Requirements

- safe against instability or collapse
- no excessive/damaging settlements
- consider environment
 - frost action
 - shrinkage/swelling
 - adjacent structure, property lines
 - ground water
 - underground defects
 - earthquake
- economics



Foundations 16
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Generalized Design Steps

- calculate loads
- characterize soil
- determine footing location and depth
- evaluate soil bearing capacity
- determine footing size (unfactored loads)
- calculate contact pressure and check stability
- estimate settlements
- design footing structure * (factored loads)


Foundations 17
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Types of Foundations

- mat foundations
- retaining walls
- basement walls
- pile foundations
- drilled piers



Foundations 19
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Types of Foundations

- spread footings
- wall footings
- eccentric footings
- combined footings
- unsymmetrical footings
- strap footings




Figure 5.1 Spread footing shapes and dimensions.


Foundations 18
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Shallow Foundations

- spread footing
 - a square or rectangular footing supporting a single column
 - reduces stress from load to size the ground can withstand




Foundations 20
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Actual vs. Design Soil Pressure

- stress distribution is a function of
 - footing rigidity
 - soil behavior



- linear stress distribution assumed

Foundations 21
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Concrete Spread Footings

- plain or reinforced
- ACI specifications
- $P_u =$ combination of factored D, L, W
- ultimate strength
 - $V_u \leq \phi V_c : \phi = 0.75$ for shear
 - plain concrete has shear strength
 - $M_u \leq \phi M_n : \phi = 0.9$ for flexure

Foundations 22
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Concrete Spread Footings

- failure modes




Figure 9.2 "Shear" failure in a spread footing loaded in a laboratory (Talbot, 1913). Observe how this failure actually is a combination of tension and shear.

shear




Figure 9.3 Flexural failure in a spread footing loaded in a laboratory (Talbot, 1913).

bending


Foundations 23
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Concrete Spread Footings

- shear failure



one way shear

two way shear

Foundations 24
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Over and Under-reinforcement

- reinforcement ratio for bending
 - $\rho = \frac{A_s}{bd}$
 - use as a design estimate to find A_s, b, d
 - max $\rho = 0.75 \rho_b$
 - minimum for slabs & footings of uniform thickness
 - $\frac{A_s}{bh} = 0.002$ grade 40/50 bars
 - $= 0.0018$ grade 60 bars

Foundations 25
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Reinforcement Length

- need length, l_d
 - bond
 - development of yield strength




Figure 6.2.1 Development of reinforcement.

Figure 6.11.2 Development length L_{dh} for hooked bar.

Foundations 26
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Column Connection

- bearing of column on footing


$$P_u \leq \phi P_n = \phi(0.85 f'_c A_1)$$

$$\phi = 0.65 \text{ for bearing}$$

- dowel reinforcement

- if $P_u > P_b$, need compression reinforcement

- min of 4 - #5 bars (or 15 metric)



Foundations 27
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Wall Footings

- continuous strip for load bearing walls


- plain or reinforced

- behavior

- wide beam shear
- bending of projection

- dimensions usually dictated by codes for residential walls

- light loads



Foundations 28
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Wall Footings - plain vs. reinforced

- trade off in amounts of material
 - can save time if cost of extra concrete is justified (plain)
 - local codes may not allow plain footings
 - with same load, plain about twice as thick as minimally reinforced footing

Foundations 29
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Eccentrically Loaded Footings

- footings subject to moments



- soil pressure resultant force may not coincide with the centroid of the footing


Foundations 30
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Differential Soil Pressure


- to avoid large rotations, limit the differential soil pressure across footing
- for rigid footing, simplification of soil pressure is a linear distribution based on constant ratio of pressure to settlement



Guidelines

- want resultant of load from pressure inside the middle third of base
 - ensures stability with respect to overturning

$$SF = \frac{M_{resist}}{M_{overturning}} = \frac{R \cdot x}{M} \geq 1.5$$



- pressure under toe (moment) $\leq q_a$
- shortcut using uniform soil pressure for design moments gives similar steel areas

Foundations 31
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Foundations 32
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Combined Footings

- supports two columns
- used when space is tight and spread footings would overlap or when at property line



- soil pressure might not be uniform
- proportion so pressure will uniform for sustained loads
- behaves like beam lengthwise

Foundations 33
Lecture 27


Architectural Structures III
ARCH 631

F2007abn

Proportioning

- uniform settling is desired
- area is proportioned with sustained column loads
- resultant coincides with centroid of footing area for uniformly distributed pressure assuming rigid footing

$$q_{max} \leq q_a$$




Foundations 35
Lecture 27

Architectural Structures III
ARCH 631


F2007abn

Combined Footing Types

- rectangular
- trapezoid




- strap or cantilever
 - prevents overturning of exterior column



- raft/mat

- more than two columns over an extended area




Foundations 34
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Multiple Column Footings

- used where bearing capacity of subsoil is so low that large bearing areas are needed
- grid foundation
 - continuous strips between columns
 - treat like rectangular combined footings with moment for beam



Foundations 36
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Multiple Column Footings

- when bearing capacity is even lower, strips in grid foundation merge into mat
 - upside down flat slab or plate





Figure 10-1 Common types of mat foundations. (a) Flat plate; (b) plate thickened under columns; (c) wall/slab; (d) plate with pedestals; (e) basement walls as part of mat.

Mat Foundations

- rigid foundations
 - soil pressures presumed linear
- flexible foundation
 - settlements and pressures no longer linear



$$q = k_s \cdot s$$


k_s is a mechanical soil property

Settling of Multiple Column Footings

- use if we can't space columns such that the centroid of foundation coincides with load resultant
 - geometry helps reduce differential settlement
 - variable soil
 - structure sensitive to differential settlements

Retaining Walls

- purpose
 - retain soil or other material
- basic parts
 - wall & base
 - additional parts
 - counterfort
 - buttress
 - key




Retaining Walls

- considerations

- overturning
- settlement
- allowable bearing pressure
- sliding
- (adequate drainage)

$$SF = \frac{M_{resist}}{M_{overturning}} \geq 1.5 - 2$$

$$SF = \frac{F_{resist}}{F_{sliding}} \geq 1.25 - 2$$



- procedure

- proportion and check stability with working loads
- design structure with factored loads

Foundations 41
Lecture 27


Architectural Structures III
ARCH 631

F2007abn

Retaining Wall Types


- “gravity” wall

- usually unreinforced
- economical & simple




- cantilever retaining wall

- common




Retaining Wall Types


- counterfort wall
 - buttress wall
 - bridge abutment
 - basement frame wall (large basement areas)
- } very tall walls (> 20 - 25 ft)



(c) Counterfort wall



(d) Buttress wall



Foundations 43
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Deep Foundations

- usage

- when spread footings, mats won't work
- when they are required to transfer the structural loads to good bearing material
- to resist uplift or overturning
- to compact soil
- to control settlements of spread or mat foundations

Foundations 44
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Deep Foundation Types

- piles - usually driven, 6"-8" ϕ , 5' +
- piers
- caissons
- drilled shafts
- bored piles
- pressure injected piles

drilled, excavated,
concreted (with or
without steel)
2.5' - 10'/12' ϕ




Foundations 45
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Deep Foundation Types



Foundations 46
Lecture 27

Architectural Structures III
ARCH 631

F2007abn

Deep Foundations

- classification
 - by material
 - by shape
 - by function (structural, compaction...)
- pile placement methods
 - driving with pile hammer (noise & vibration)
 - driving with vibration (quieter)
 - jacking
 - drilling hole & filling with pile or concrete




Foundations 47
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Piles Classified By Material

- timber
 - use for temporary construction
 - to densify loose sands
 - embankments
 - fenders, dolphins (marine)
- concrete
 - precast: ordinary reinforcement or prestressed
 - designed for axial capacity and bending with handling




Foundations 48
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Piles Classified By Material

- steel
 - rolled HP shapes or pipes
 - pipes may be filled with concrete
 - HP displaces little soil and may either break small boulders or displace them to the side




Foundations 49
Lecture 25

Architectural Structures III
ARCH 631


F2009abn

Piles Classified By Function

- end bearing pile (point bearing)



- friction piles (floating)



Foundations 50
Lecture 27

Architectural Structures III
ARCH 631


F2007abn

Piles Classified By Function

- combination friction and end bearing


- uplift/tension piles

structures that float,
towers



- batter piles

angled,
cost more,
resist large
horizontal loads



Foundations 51
Lecture 27


Architectural Structures III
ARCH 631

F2007abn

Piles Classified By Function

- fender piles, dolphins, pile clusters

large # of piles
in a small area



- compaction piles

- used to densify loose sands

- drilled piers

- eliminate need for pile caps
- designed for bearing capacity (not slender)


Foundations 52
Lecture 25

Architectural Structures III
ARCH 631

F2009abn

Pile Caps and Grade Beams

- like multiple column footing*
- more shear areas to consider*



Foundations 53
Lecture 25

Architectural Structures III
ARCH 631

F2009abn